
MEUCCI ENGINE ECU DECODING VERSION 1.0

ALFA

BOSCH EDC15C5-X EEPROM 95P08 (P)
BOSCH EDC15C6 EEPROM 95P08 (P)
BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C7 EEPROM 95P08 (P)
BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)
BOSCH EDC16C39 JTD 1.9L EEPROM 95320 (P) + CRASH RESET
BOSCH EDC16C8 EEPROM 95160 (P)
BOSCH EDC16C9 EEPROM 95160 (P)
BOSCH M2.10.3 EEPROM 24C02 (T.P)
BOSCH M2.10.4 EEPROM 24C02 (T.P)
BOSCH ME7.1.1 EEPROM 25/95080 (P)
BOSCH MED7.6.1 EEPROM 25/95080 (P)
BOSCH MED7.6.2 EEPROM 25/95080 (P)
BOSHC EDC1.3.1 MSA11-4 EEPROM 93C46 DX & SX (T.P)
MAGNETI MARELLI IAW 18F.XX MCU 68HC11F1 (P)
MAGNETI MARELLI IAW 4Q-J-W MCU 68HC11E1 (T.P)
MAGNETI MARELLI IAW 8F.XX MCU 68HC11F1 (T.P)

APRILIA

MAGNETI MARELLI 5AM.XX EEPROM 95160 (P)

AUDI

BOSCH EDC1.3.1 MSA11 EEPROM 93C46 DX (T)
BOSCH EDC15M-5.X EEPROM 24C04 (T)
BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC15VM+ EEPROM 24C04 (T)
BOSCH EDC16CP34 EEPROM 95320 (T)
BOSCH EDC16U1 EEPROM 95320 (T)
BOSCH EDC16U31 EEPROM 95320 (T)
BOSCH EDC16U34 EEPROM 95320 (T)
BOSCH M2.3.2 EPROM 27C512 T
BOSCH M3.2.1 EEPROM 24C02 (T)
BOSCH M3.8.X EEPROM 24C02 (T)
BOSCH M5.4.1 EEPROM 24C02 (T)

BOSCH M5.9.2 EEPROM 24C02 (T)
BOSCH ME7XX EEPROM 25/95040 T
BOSCH MSA EDC15-X EEPROM 24C02 ALL ECU (T)
DIGIFANT 3.2 EPROM 27C256 (T)
SIEMENS SIMOS 2.X 2 PLUG FLASH 29F200 (T)
SIEMENS SIMOS1.X 1 PLUG EEPROM 93C56 (T)
SIEMENS SIMOS2.X 2 PLUG EPROM 27C010 (T)
SIEMENS SIMOS3.X 2 PLUG EEPROM 93C76 (T)

BLAZER

BOSCH M2.8 EEPROM 24C02 (T)

BMW

BOSCH EDC15C4-X EEPROM 95P08 (P)
BOSCH EDC15M-6 DDE 3.0 EEPROM 24C04 P
BOSCH MSA 15.5 EPROM 93C46 (T)
SIEMENS BMS46 FLASH 29F200 (P) RESET ROLLING CODE
SIEMENS MMS50 FLASH 29F200 (P) RESET ROLLING CODE
SIEMENS MMS52 FLASH 29F200 (P) RESET ROLLING CODE
SIEMENS MS41 FLASH 29F200 (T)
SIEMENS MS42 FLASH 29F400 ROLLING CODE RESET

CHEVROLET

BOSCH M2.8 EEPROM 24C02 (T)
GM MULTEC MCU 68HC11F1 PLUG RED & WRITE (T)

CHRYSLER

BOSCH EDC MSA 15.5-5.3 EEPROM 24C04 P
BOSCH EDC MSA 15.5-5.3 EEPROM 24C04 T
BOSCH EDC MSA 15.5-5.5 EEPROM 24C02 P
BOSCH EDC MSA 15.5-5.5 EEPROM 24C02 T

CITROEN

BOSCH EDC15C2-6 EEPROM 95P08 (T)
BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C7 EEPROM 95P08 (P)
BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)
BOSCH MA3.0 EEPROM 93CS46 (T.P)
BOSCH MA3.1 EEPROM 93CS46 (T.P)
BOSCH MP3.1 EEPROM 93CS46 (T.P)
BOSCH MP3.2 EEPROM 93CS46 (T.P)
BOSCH MP5.1 EEPROM 93CS46 (T.P)

BOSCH MP5.1.1 EEPROM 93CS46 (T.P)
BOSCH MP5.2 EEPROM 93CS46 (T.P)
BOSCH MP7.0 EEPROM 24C02 (P)
BOSCH MP7.2 EEPROM 24C02 (T.P)
BOSCH MP7.3 EEPROM 24C02 (T.P)
BOSHC EDC 1.3.8 MSA11-3 EEPROM 93C46 DX & SX (T.P)
LUCAS EPIC MCU 86HC11E9 (T.P)
MAGNETI MARELLI 48P.XX FLASH 29F400 (P) ROLLING CODE RESET
MAGNETI MARELLI 48P3X EEPROM 25/95080 (T.P)
MAGNETI MARELLI 4MP.XX FLASH 29F200 (T.P) ROLLING CODE RESET
MAGNETI MARELLI 5NP EEPROM 95160 (P)
MAGNETI MARELLI 6LPX MCU ST10F280 (P)
MAGNETI MARELLI G6 MCU 68HCA1 (T.P)
MAGNETI MARELLI IAW 8P.XX MCU 68HC11A1 (T.P)
SAGEM 2000 EEPROM 25/95080 P
SID 801 EEPROM 95C56 (P)
SID 801A EEPROM 95C56 (P)
SIEMENS SID 801 FLASH 29F400 ROLLING CODE RESET
SIEMENS SID 801A FLASH 29F400 ROLLING CODE RESET
SIEMENS SID 804 FLASH 29F400 ROLLING CODE RESET
SIEMENS SID 806 FLASH 29F400 ROLLING CODE RESET

DACIA

DELPHI TRW EEPROM 25/95080 (P)
SIEMENS SIRIUS32 FLASH 29F200 (P) ROLLING CODE RESET
SIEMENS SIRIUS34 FLASH 29F200 (P) ROLLING CODE RESET

DAEWOO

KEMSCO D3 FLASH 29F200 (P) ROLLING CODE RESET

DAF TRUCK

BOSCH EDC7CX EEPROM 95640 (P)
BOSCH MS 6.2 EEPROM 24C16 (T.P)

DODGE

BOSCH EDC MSA 15.5-5.3 EEPROM 24C04 P
BOSCH EDC MSA 15.5-5.3 EEPROM 24C04 T
BOSCH EDC MSA 15.5-5.5 EEPROM 24C02 P
BOSCH EDC MSA 15.5-5.5 EEPROM 24C02 T

DUCATI

MAGNETI MARELLI 5AM.XX EEPROM 95160 (P)

FENDT TRACTOR

BOSCH MS 6.4 EEPROM 24C16 (T.P)

FIAT

BOSCH EDC15C2-6 EEPROM 95P08 (T)
BOSCH EDC15C5-X EEPROM 95P08 (P)
BOSCH EDC15C6 EEPROM 95P08 (P)
BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C7 EEPROM 95P08 (P)
BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C8-1.31 EEPROM 95320 (P)
BOSCH EDC16C39 JTD 1.9L EEPROM 95320 (P) + CRASH RESET
BOSCH EDC16C8 EEPROM 95160 (P)
BOSCH EDC16C9 EEPROM 95160 (P)
BOSCH M1.7.3 EEPROM 24C02 (T.P)
BOSCH M2.10.3 EEPROM 24C02 (T.P)
BOSCH M2.10.4 EEPROM 24C02 (T.P)
BOSCH ME7.9.10 EEPROM 25/95080 (P)
BOSCH ME7.9.6 EEPROM 25/95080 (P)
BOSCH MP3.2 EEPROM 93CS46 (T.P)
BOSHC EDC1.3.1 MSA11-4 EEPROM 93C46 DX & SX (T.P)
GM MPI MCU 68HC11F1 PLUG RED & BROWN (T.P)
GM MPI MCU 68HC11F1 PLUG RED & WRITE (T.P)
LUCAS DCU3F EEPROM 25/95080 (P)
LUCAS EPIC MCU 86HC11E9 (T.P)
MAGENTI MARELLI 49F EEPROM 25/95040 (P)
MAGENTI MARELLI 4EF EEPROM 25/95080 (P)
MAGENTI MARELLI 4GF EEPROM 25/95040 (P)
MAGENTI MARELLI MJD 6F3 EEPROM 95320 (P) + CRASH RESET
MAGENTI MARELLI MJD 6JF EEPROM 95320 (P)
MAGNETI MARELLI 1AG7.XX MCU 68HC11F1 (T.P)
MAGNETI MARELLI 48P.XX FLASH 29F400 (P) ROLLING CODE RESET
MAGNETI MARELLI 48P3X EEPROM 25/95080 (T.P)
MAGNETI MARELLI 49F/4GF EEPROM 25/95040 (T)
MAGNETI MARELLI 4AF EEPROM 95160 (P)
MAGNETI MARELLI 4AF.XX EEPROM 95160 (T)
MAGNETI MARELLI 4MP.XX FLASH 29F200 (T.P) ROLLING CODE RESET
MAGNETI MARELLI 4SF MCU ST10F280 (P)
MAGNETI MARELLI 59F.XX MCU / EEPROM ST10F168/269 (P)
MAGNETI MARELLI 59FBTX EEPROM 25/95160(P)

MAGNETI MARELLI 5AF.XX MCU / EEPROM ST10F168/269 (P)
MAGNETI MARELLI 5NF.XX EEPROM 95160 (P)
MAGNETI MARELLI 5NFXX EEPROM 95160 T
MAGNETI MARELLI 5SF MCU ST10F280 (P)
MAGNETI MARELLI IAW 16F.XX MCU 68HC11F1 (T.P)
MAGNETI MARELLI IAW 18F.XX MCU 68HC11F1 (P)
MAGNETI MARELLI IAW 4Q-J-W MCU 68HC11E1 (T.P)
MAGNETI MARELLI IAW 8F.XX MCU 68HC11F1 (T.P)
MAGNETI MARELLI IAW 8P.XX MCU 68HC11A1 (T.P)
MARELLI 1AB.XX EPROM 27C512 (T)
MARELLI 1AF.XX EPROM 27C512 (T)

FORD

BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC16C3 EEPROM 95160 (P)
BOSCH M3.8.1 EEPROM 24C02 (T)
BOSCH ME7.1 EEPROM 25/95040 T
BOSCH MSA EDC15-X EEPROM 24C02 ALL ECU (T)

HONDA

BOSCH EDC15C7 EEPROM 95P08 P
BOSHC EDC 1.3.1 MSA11-10 EEPROM 93C46 DX & SX (T.P)
HITACHI P9L EEPROM 93C56 T.P

HYUNDAI

BOSCH EDC 15C7-X EEPROM 98P08 (P)
SIEMENS S-11 1-5L DOHC EPROM 27C512 (T)

ISUZU

BOSCH EDC15M EEPROM 24C04 (P)

IVECO TRUCK

BOSCH M.S 6.3 EEPROM 24C16 (T.P)
BOSCH EDC15C8-1.31 EEPROM 95320 (P)
BOSCH EDC7CX EEPROM 95640 (P)
BOSCH M.S 6.2 EEPROM 24C16 (T.P)

JEEP

BOSCH EDC MSA 15.5-5.3 EEPROM 24C04 P
BOSCH EDC MSA 15.5-5.3 EEPROM 24C04 T
BOSCH EDC MSA 15.5-5.5 EEPROM 24C02 P

BOSCH EDC MSA 15.5-5.5 EEPROM 24C02 T

KIA

BOSCH EDC 15C7-X EEPROM 98P08 (P)

SIEMENS S-11 1-5L DOHC EPROM 27C512 (T)

LADA

BOSCH M1.5.4 EEPROM 24C02 (T)

BOSCH MP7.0 EEPROM 24C02 (T)

BOSCH MP7.3 EEPROM 24C02 (T)

LANCIA

BOSCH EDC15C2-6 EEPROM 95P08 (T)

BOSCH EDC15C5-X EEPROM 95P08 (P)

BOSCH EDC15C6 EEPROM 95P08 (P)

BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)

BOSCH EDC15C7 EEPROM 95P08 (P)

BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)

BOSCH EDC16C8 EEPROM 95160 (P)

BOSCH EDC16C9 EEPROM 95160 (P)

BOSCH M1.7.3 EEPROM 24C02 (T.P)

BOSCH M2.10.3 EEPROM 24C02 (T.P)

BOSCH M2.10.4 EEPROM 24C02 (T.P)

BOSCH ME7.9.10 EEPROM 25/95080 (P)

BOSCH MP3.2 EEPROM 93CS46 (T.P)

BOSHC EDC1.3.1 MSA11-4 EEPROM 93C46 DX & SX (T.P)

LUCAS EPIC MCU 86HC11E9 (T.P)

MAGENTI MARELLI 49F EEPROM 25/95040 (P)

MAGENTI MARELLI 4EF EEPROM 25/95080 (P)

MAGENTI MARELLI 4GF EEPROM 25/95040 (P)

MAGENTI MARELLI MJD 6F3 EEPROM 95320 (P) + CRASH RESET

MAGENTI MARELLI MJD 6JF EEPROM 95320 (P)

MAGNETI MARELLI 48P.XX FLASH 29F400 (P) ROLLING CODE RESET

MAGNETI MARELLI 48P3X EEPROM 25/95080 (T.P)

MAGNETI MARELLI 49F/4GF EEPROM 25/95040 (T)

MAGNETI MARELLI 4AF EEPROM 95160 (P)

MAGNETI MARELLI 4MP.XX FLASH 29F200 (T.P) ROLLING CODE RESET

MAGNETI MARELLI 59F.XX MCU / EEPROM ST10F168/269 (P)

MAGNETI MARELLI 5AF.XX MCU / EEPROM ST10F168/269 (P)

MAGNETI MARELLI 5NF.XX EEPROM 95160 (P)

MAGNETI MARELLI 5NFXX EEPROM 95160 T

MAGNETI MARELLI 5SF MCU ST10F280 (P)

MAGNETI MARELLI IAW 16F.XX MCU 68HC11F1 (T.P)
MAGNETI MARELLI IAW 18F.XX MCU 68HC11F1 (P)
MAGNETI MARELLI IAW 4Q-J-W MCU 68HC11E1 (T.P)
MAGNETI MARELLI IAW 8F.XX MCU 68HC11F1 (T.P)
MAGNETI MARELLI IAW 8P.XX MCU 68HC11A1 (T.P)
MARELLI 1AB.XX EPROM 27C512 (T)
MARELLI 1AF.XX EPROM 27C512 (T)

LAND ROVER

BOSCH EDC15C4-X EEPROM 95P08 (P)
BOSCH EDC15M-6 DDE 3.0 EEPROM 24C04 P
BOSCH MSA 15.5 EPROM 93C46 (T)
BOSHC EDC 1.3.1 MSA11-10 EEPROM 93C46 DX & SX (T.P)
MEMS MKC EEPROM 93C46 (T)

LEXUS

NIPPON DENSO GASOLINE EEPROM 93C46 (P)

MAN TRUCK

BOSCH EDC7CX EEPROM 95640 (P)
BOSCH MS 6.1 EEPROM 24C16 (T.P)

MAZDA

BOSCH EDC16C3.9 EEPROM 95160 (P)

MERCEDES

BOSCH EDC15.5-X EEPROM 24C02 P
BOSCH EDC15C0-X EEPROM 24C04 P + START ERROR RESET
BOSCH EDC15C6 EEPROM 95P08 AUTOCODING
BOSCH EDC15C6 EEPROM 95P08 P + START ERROR RESET
BOSCH EDC16C2 EEPROM 95160 (P)
SIEMENS VDO MSE H10 FLASH 29F200 (P) RESET ROLLING CODE
SIEMENS VDO MSM 1.X FLASH 29F200 (P) RESET ROLLING CODE

MERCEDES TRUCK

TEMIC EEPROM 93C66 (P)

MG

BOSCH EDC15C4-X EEPROM 95P08 (P)
BOSHC EDC 1.3.1 MSA11-10 EEPROM 93C46 DX & SX (T.P)
MEMS MKC EEPROM 93C46 (T)

MINI

BOSCH EDC15C4-X EEPROM 95P08 (P)
SIEMENS EMS 2 FLASH 29F400 (P) ROLLING CODE RESET
SIEMENS EMS 2 FLASH 29F400 (T) ROLLING CODE RESET

MITSUBISHI

BOSCH EDC15C3 EEPROM 95P08 (P)

MOTO GUZZI

MAGNETI MARELLI 5AM.XX EEPROM 95160 (P)

MOTO MORINI

MAGNETI MARELLI 5AM.XX EEPROM 95160 (P)

MV AGUSTA

MAGNETI MARELLI 5AM.XX EEPROM 95160 (P)

NEW HOLLAND

BOSCH EDC7CX EEPROM 95640 (P)

NISSAN

BOSCH EDC15C3 EEPROM 95P08 (P)
BOSCH M1.9.5 EEPROM 93C46 T.P
BOSCH MSA 15.5-6 EEPROM 24C02 P
BOSCH MSA 15.5-6 EEPROM 24C02 T
DELPHI TRW EEPROM 25/95080 (P)

NISSAN TRUCK

BOSCH MS 6.4 EEPROM 24C16 (T.P)

OPEL

BOSCH EDC 1.3.1 MSA 11-10 EEPROM 93C46 DX & SX (T.P)
BOSCH EDC MSA 15.6 EEPROM 24C02 (P)
BOSCH EDC15C3 EEPROM 95P08 (P)
BOSCH EDC15M EEPROM 24C04 (P)
BOSCH M1.5.X EEPROM 24C02 T
BOSCH M2.8 EEPROM 24C02 (T)
BOSCH ME7.9.6 EEPROM 25/95080 (P)
GM MPI MCU 68HC11F1 PLUG VIOLET (T.P)
GM MULTEC MCU 68HC11F1 PLUG BLU & GREY (T)
GM MULTEC MCU 68HC11F1 PLUG LIGHT BLUE (T)
GM MULTEC MCU 68HC11F1 PLUG RED & BROWN (T)
GM MULTEC MCU 68HC11F1 PLUG RED & WRITE (T)
MAGNETI MARELLI MJD 6JF GM EEPROM 95320 (P)

SIMTEC 56.1 EEPROM 93C56 (T)
SIMTEC 56.1 EEPROM 93C56 (P)
SIMTEC 56.5 EPROM 27C010 (T)

PEUGEOT

BOSCH EDC15C2-6 EEPROM 95P08 (T)
BOSCH EDC15C6 EEPROM 95P08 (P)
BOSCH EDC15C6 FLASH 29F400 EURO 3 (T)
BOSCH EDC15C7 FLASH 29F400 EURO 3 (T)
BOSCH MA3.0 EEPROM 93CS46 (T.P)
BOSCH MA3.1 EEPROM 93CS46 (T.P)
BOSCH MP3.1 EEPROM 93CS46 (T.P)
BOSCH MP3.2 EEPROM 93CS46 (T.P)
BOSCH MP5.1 EEPROM 93CS46 (T.P)
BOSCH MP5.1.1 EEPROM 93CS46 (T.P)
BOSCH MP5.2 EEPROM 93CS46 (T.P)
BOSCH MP7.0 EEPROM 24C02 (P)
BOSCH MP7.2 EEPROM 24C02 (T.P)
BOSCH MP7.3 EEPROM 24C02 (T.P)
BOSHC EDC 1.3.8 MSA11-3 EEPROM 93C46 DX & SX (T.P)
LUCAS EPIC MCU 86HC11E9 (T.P)
MAGNETI MARELLI 48P.XX FLASH 29F400 (P) ROLLING CODE RESET
MAGNETI MARELLI 48P3X EEPROM 25/95080 (T.P)
MAGNETI MARELLI 4MP.XX FLASH 29F200 (T.P) ROLLING CODE RESET
MAGNETI MARELLI 5NP EEPROM 95160 (P)
MAGNETI MARELLI 6LPX MCU ST10F280 (P)
MAGNETI MARELLI G6 MCU 68HCA1 (T.P)
MAGNETI MARELLI IAW 8P.XX MCU 68HC11A1 (T.P)
SAGEM 2000 EEPROM 25/95080 P
SID 801 EEPROM 95C56 (P)
SID 801A EEPROM 95C56 (P)
SIEMENS SID 801 FLASH 29F400 ROLLING CODE RESET
SIEMENS SID 801A FLASH 29F400 ROLLING CODE RESET
SIEMENS SID 804 FLASH 29F400 ROLLING CODE RESET
SIEMENS SID 806 FLASH 29F400 ROLLING CODE RESET

PORSCHE

BOSCH ME7.1 EEPROM 25/95040 (P)

RENAULT

BOSCH EDC16C3 EEPROM 95160 (P)
BOSCH EDC15.X 1 PLUG EEPROM 24C02 (P)

BOSCH EDC15.X 2 PLUG EEPROM 24C04 (P)
BOSCH EDC15C3 EEPROM 95P08 (P)
BOSCH MP7.0 EEPROM 24C02 (P)
DELPHI TRW EEPROM 25/95080 (P)
LUCAS DCU3R EEPROM 25/95080 (P)
MAGNETI MARELLI 5NR2-C5 PCB EEPROM 95160 (T)
MAGNETI MARELLI 8R.30 MCU 68HC11A1 (T.P)
SIEMENS EMS3132 FLASH 29F200 (P) ROLLING CODE RESET
SIEMENS EMS3134 FLASH 29F400 (P) ROLLING CODE RESET
SIEMENS FENIX 3 MCU 68HC11E1 (T.P)
SIEMENS SIRIUS 35 FLASH 29F400 (P) ROLLING CODE RESET
SIEMENS SIRIUS32 FLASH 29F200 (P) ROLLING CODE RESET
SIEMENS SIRIUS34 FLASH 29F200 (P) ROLLING CODE RESET
SIEMENS SIRIUS34 FLASH 29F400 (P) ROLLING CODE RESET

RENAULT TRUCKS

BOSCH M.S 6.3 EEPROM 24C16 (T.P) TRUKS
BOSCH MS 6.2 EEPROM 24C16 (T.P)

ROVER

BOSCH EDC15C4-X EEPROM 95P08 (P)
BOSHC EDC 1.3.1 MSA11-10 EEPROM 93C46 DX & SX (T.P)
MEMS MKC EEPROM 93C46 (T)
ROVER MSB EEPROM 93C46 T

SAAB

BOSCH EDC15M EEPROM 24C04 (P)

SCANIA TRUCK

BOSCH MS 6.2 EEPROM 24C16 (T.P)

SEAT

BOSCH EDC1.3.1 MSA11 EEPROM 93C46 DX (T)
BOSCH EDC15M-5.X EEPROM 24C04 (T)
BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC15VM+ EEPROM 24C04 (T)
BOSCH EDC16CP34 EEPROM 95320 (T)
BOSCH EDC16U1 EEPROM 95320 (T)
BOSCH EDC16U31 EEPROM 95320 (T)
BOSCH EDC16U34 EEPROM 95320 (T)

BOSCH M3.2.1 EEPROM 24C02 (T)
BOSCH M3.8.X EEPROM 24C02 (T)
BOSCH M5.4.1 EEPROM 24C02 (T)
BOSCH M5.9.2 EEPROM 24C02 (T)
BOSCH ME7XX EEPROM 25/95040 T
BOSCH MSA EDC15-X EEPROM 24C02 ALL ECU (T)
DIGIFANT 3.2 EPROM 27C256 (T)
MAGNETI MARELLI 16S.XX MCU 68HC11F1 (T.P)
SIEMENS SIMOS 2.X 2 PLUG FLASH 29F200 (T)
SIEMENS SIMOS1.X 1 PLUG EEPROM 93C56 (T)
SIEMENS SIMOS2.X 2 PLUG EPROM 27C010 (T)
SIEMENS SIMOS3.X 2 PLUG EEPROM 93C76 (T)

SKODA

BOSCH EDC1.3.1 MSA11 EEPROM 93C46 DX (T)
BOSCH EDC15M-5.X EEPROM 24C04 (T)
BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)
BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC15VM+ EEPROM 24C04 (T)
BOSCH EDC16CP34 EEPROM 95320 (T)
BOSCH EDC16U1 EEPROM 95320 (T)
BOSCH EDC16U31 EEPROM 95320 (T)
BOSCH EDC16U34 EEPROM 95320 (T)
BOSCH M3.2.1 EEPROM 24C02 (T)
BOSCH M3.8.X EEPROM 24C02 (T)
BOSCH M5.4.1 EEPROM 24C02 (T)
BOSCH M5.9.2 EEPROM 24C02 (T)
BOSCH ME7XX EEPROM 25/95040 T
BOSCH MSA EDC15-X EEPROM 24C02 ALL ECU (T)
DIGIFANT 3.2 EPROM 27C256 (T)
SIEMENS SIMOS 2.X 2 PLUG FLASH 29F200 (T)
SIEMENS SIMOS1.X 1 PLUG EEPROM 93C56 (T)
SIEMENS SIMOS2.X 2 PLUG EPROM 27C010 (T)
SIEMENS SIMOS3.X 2 PLUG EEPROM 93C76 (T)

SMART

BOSCH EDG15C-5.1 EEPROM 95P08 (P)
BOSCH MEG 1.0 EEPROM 24C02 (P)

SUZUKI

BOSCH EDC15C2-6 EEPROM 95P08 (T)

DELPHI TRW EEPROM 25/95080 (P)
DENSO EPROM 27C256 (T)
LUCAS DCU3R EEPROM 25/95080 (P)
MAGNETI MARELLI MJD 6JF GM EEPROM 95320 (P)
SIEMENS SID 801 5WS4 EEPROM 93C56 (T.P)
SIEMENS SID 801 FLASH 29F400 ROLLING CODE RESET
SIEMENS SID 801A EEPROM 93C56 (T.P)
SIEMENS SID 801A FLASH 29F400 ROLLING CODE RESET

TOYOTA

BOSCH EDC16CXX EEPROM 95160 (P)
NIPPON DENSO D4D EEPROM 93C86 (T)
NIPPON DENSO GASOLINE EEPROM 93C46 (P)

VAUXHALL

BOSCH EDC 1.3.1 MSA 11-10 EEPROM 93C46 DX & SX (T.P)
BOSCH EDC MSA 15.6 EEPROM 24C02 (P)
BOSCH EDC15C3 EEPROM 95P08 (P)
BOSCH EDC15M EEPROM 24C04 (P)
BOSCH M1.5.X EEPROM 24C02 T
BOSCH M2.8 EEPROM 24C02 (T)
BOSCH ME7.9.6 EEPROM 25/95080 (P)
GM MULTEC MCU 68HC11F1 PLUG BLU & GREY (T)
GM MULTEC MCU 68HC11F1 PLUG LIGHT BLUE (T)
GM MULTEC MCU 68HC11F1 PLUG RED & BROWN (T)
GM MULTEC MCU 68HC11F1 PLUG RED & WRITE (T)
MAGNETI MARELLI MJD 6JF GM EEPROM 95320 (P)
SIMTEC 56.1 EEPROM 93C56 (P)
SIMTEC 56.5 EPROM 27C010 (T)

VOLVO

BOSCH EDC15.X 1 PLUG EEPROM 24C02 (P)
SIEMENS SIRIUS32 FLASH 29F200 (P) ROLLING CODE RESET

VOLVO TRUCKS

BOSCH EDC7CX EEPROM 95640 (P)

VW

BOSCH EDC1.3.1 MSA11 EEPROM 93C46 DX (T)
BOSCH EDC15M-5.X EEPROM 24C04 (T)
BOSCH EDC15P EEPROM 24C04 (T)
BOSCH EDC15P-6 MICRO 1037355944 EEPROM 24C04 (T)

BOSCH EDC15V EEPROM 24C04 (T)
BOSCH EDC15VM+ EEPROM 24C04 (T)
BOSCH EDC16CP34 EEPROM 95320 (T)
BOSCH EDC16U1 EEPROM 95320 (T)
BOSCH EDC16U31 EEPROM 95320 (T)
BOSCH EDC16U34 EEPROM 95320 (T)
BOSCH M2.3.2 EPROM 27C512 T
BOSCH M3.2.1 EEPROM 24C02 (T)
BOSCH M3.8.X EEPROM 24C02 (T)
BOSCH M5.4.1 EEPROM 24C02 (T)
BOSCH M5.9.2 EEPROM 24C02 (T)
BOSCH ME7XX EEPROM 25/95040 T
BOSCH MSA EDC15-X EEPROM 24C02 ALL ECU (T)
DIGIFANT 3.2 EPROM 27C256 (T)
SIEMENS SIMOS 2.X 2 PLUG FLASH 29F200 (T)
SIEMENS SIMOS1.X 1 PLUG EEPROM 93C56 (T)
SIEMENS SIMOS2.X 2 PLUG EPROM 27C010 (T)
SIEMENS SIMOS3.X 2 PLUG EEPROM 93C76 (T)